



DRILL 3/8" DIA HOLES THRU "A" BOARDS AT THE SAME TIME, MARKING TOPS AND OUTSIDE EDGES TO ENSURE PROPER ALIGNMENT DURING ASSEMBLY. REPEAT WITH "B"s.